



• All service should be performed by qualified personnel - power supply to be disconnected prior to installation.

• Connections made must comply with local regulations and the national electrical code. Contact Solera for additional information on installations.

Installation Instructions: DIX

1
Connect the incoming power wires to the leads inside the bollard housing.

2
Place the bollard base plate weld assembly over the qty (4) anchor bolts assembly.

3
Secure the bollard base plate with the nuts and washers supplied.

4
Place the bollard housing over the base plate (flush with the ground).

5
Secure the bollard housing using the supplied qty (8) screws and screw them into each of the 7 threaded holes.

