



- All service should be performed by qualified personnel - power supply to be disconnected prior to installation.
- Connections made must comply with local regulations and the national electrical code. Contact Solera for additional information on installations.

Installation Instructions: GROTTO

1
Install anchor bolts according to provided bolt pattern. (2.5" X 6.5"). See below for more details.

2
Place the bollard base plate using qty (4) nuts, and washers.

3
Fasten the surface mounting base plate using qty (4) nuts, and washers.

4
Connect incoming power wires to the leads inside the bollard housing.

5
Place bollard housing over surface mounting base plate (flush with the ground) and align fastener apertures.

6
Screw qty (6) flat head screw (supplied) into base plate threaded holes to secure bollard housing to base plate.

