



- All service should be performed by qualified personnel - power supply to be disconnected prior to installation.
- Connections made must comply with local regulations and the national electrical code. Contact Solera for additional information on installations.

Installation Instructions: WL3

1
Remove qty (2) cover mtg. screws and open front hinged cover.

2
Temporarily remove gear tray assembly qty (4) screws.

3
Drill qty (4) 0.218" dia. holes in each corner (approx. 1") of the back wall housing.

4
Make all the necessary power wire connections in the junction box.

5
Position fixture over the center of the junction box. Mark on the wall, (4) locations of lag screws. Secure fixture to the wall.

6
Re-install the gear tray back to the back wall housing using qty (4) screws.

ADDITIONAL NOTES:
If mounting on walls with rough or uneven surfaces, silicone must be applied around the edges of the housing between wall and the fixture.

