

Toll free: 1-877-765-3722

Phone: 905-457-4777

www.soleracorp.com





- All service should be performed by qualified personnel power supply to be disconnected prior to installation.
- Connections made must comply with local regulations and the national electrical code. Contact Solera for additional information on installations.


## **Installation Instructions: CORVUS**

Make all the necessary power wire connections in the junction box.

Mount the LEDs/driver mtg. bracket to the junction box with supplied screws qty (2).

Make all the necessary connections in the junction box.

Position casted housing/lens assembly over center of the junction box and secure to LEDs/Driver mtg. bracket with supplied screws qty (2). ADDITIONAL NOTES: If mounting on walls with rought or uneven surfaces, silicone must be applied around the edges of the housing between wall and the fixture.



2019